




## 電子遊戲機說明書


機具名稱	中文：金龍彩 原文：DRAGON CASH
遊 戲 流 程	
遊 戲 說 明	<ol style="list-style-type: none"> <li>1. 本遊戲機台為 5 輪 243 線由「沖天炮、龍、聚寶盆、蟾蜍、鯉魚、蝙蝠、A、K、Q、J、10」與五個特殊物件等 16 種圖案組合之滾輪遊戲(無網際網路功能不可上網連線)。</li> <li>2. 玩家可投入代幣、紙代幣或開分(每枚代幣兌換比率可依店家需求做設定調整)，每次押分最少 180 分，最多 680 分。</li> <li>3. 按下開始鍵啟動遊戲，並可按停止鍵使滾輪立即停止。當滾輪停止後，螢幕出現中獎連線，即中倍率表分數獎項，每次中獎分數最少 8 分，中獎分數最多 880 分(依各中獎圖案不同而定)。</li> <li>4. 免費遊戲：遊戲畫面上出現 3 個以上的沖天炮圖案，即進入免費遊戲，免費遊戲次數歸零，返回主遊戲。</li> <li>5. 特別遊戲：主遊戲與免費遊戲畫面上出現 6 個以上特別物件，即可進行特別遊戲。特別遊戲中，特別物件內的分數，即為玩家所贏得的分數。若特別物件內出現超級大獎、特大獎、大獎、小獎、迷你獎等特別獎圖案，玩家即贏得左邊欄位內相對應的特別獎獎項。最少 10 倍，最多 5000 倍。若玩家於特別遊戲內出現全盤特別物件，則特別遊戲贏分乘以兩倍(不含特別獎)。</li> <li>6. 廣播報獎系統之主機板放置於場內其中一台遊戲主機內，不具備網際網路功能，無法跨店使用。廣播報獎系統可使用附件中之顯示設備來顯示畫面，也可由業者自行搭配其他顯示設備作為顯示器。</li> <li>7. 本機台使用訊號線與廣播報獎系統連結，可連結單台或多台單機使用，最大到 80 台單機，各機台間各自獨立，無相互連接。多台單機串聯廣播報獎系統時，使用一般 HUB，將多台單機遊戲資訊之訊號透過內部區域網路傳回廣播報獎系統，最後呈現在螢幕畫面上。</li> <li>8. 廣播報獎系統內無任何遊戲內容，與本機具連結時，不影響本機具之倍率及螢幕所顯示之積分分數。廣播報獎系統螢幕會出現 JP1、JP2、JP3 等三個積分。</li> <li>9. 各積分起始值分可依業者經營自行調整。玩家每押分 10 分，個積分向上累積 0.01 分，在玩家遊戲過程中積分會隨機送出。</li> <li>10. 玩家贏得分數後可選擇退出代幣、洗分或繼續進行本遊戲，一直到分數玩完為止，本遊戲退出之代幣可兌換等值於新台幣二千元以下的禮品，但不可兌換現金。</li> </ol>
圖 片 介 紹	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>【主遊戲】</p> </div> <div style="text-align: center;">  <p>【免費遊戲】</p> </div> </div>

機具名稱	中文：金龍彩 原文：DRAGON CASH																																																																								
圖 片 介 紹																																																																									
	<p style="text-align: center;"><b>【特別遊戲】</b></p> <table border="1" data-bbox="375 660 1364 952"> <tr> <td>一般物件/ 所有押分對 應分數</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>5連線</td> <td>880分</td> <td>580分</td> <td>580分</td> <td>480分</td> <td>480分</td> <td>88分</td> <td>88分</td> <td>88分</td> <td>88分</td> <td>88分</td> <td>5個24次免費遊戲</td> </tr> <tr> <td>4連線</td> <td>280分</td> <td>180分</td> <td>180分</td> <td>88分</td> <td>88分</td> <td>18分</td> <td>18分</td> <td>18分</td> <td>18分</td> <td>18分</td> <td>4個16次免費遊戲</td> </tr> <tr> <td>3連線</td> <td>180分</td> <td>88分</td> <td>88分</td> <td>48分</td> <td>48分</td> <td>8分</td> <td>8分</td> <td>8分</td> <td>8分</td> <td>8分</td> <td>3個8次免費遊戲</td> </tr> <tr> <td>特殊物件</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>押分倍數</td> <td>5000~ 2500倍</td> <td>2000倍~ 1600倍</td> <td>1000倍~ 600倍</td> <td>10000分</td> <td>5000分</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table>	一般物件/ 所有押分對 應分數												5連線	880分	580分	580分	480分	480分	88分	88分	88分	88分	88分	5個24次免費遊戲	4連線	280分	180分	180分	88分	88分	18分	18分	18分	18分	18分	4個16次免費遊戲	3連線	180分	88分	88分	48分	48分	8分	8分	8分	8分	8分	3個8次免費遊戲	特殊物件												押分倍數	5000~ 2500倍	2000倍~ 1600倍	1000倍~ 600倍	10000分	5000分						
	一般物件/ 所有押分對 應分數																																																																								
	5連線	880分	580分	580分	480分	480分	88分	88分	88分	88分	88分	5個24次免費遊戲																																																													
	4連線	280分	180分	180分	88分	88分	18分	18分	18分	18分	18分	4個16次免費遊戲																																																													
3連線	180分	88分	88分	48分	48分	8分	8分	8分	8分	8分	3個8次免費遊戲																																																														
特殊物件																																																																									
押分倍數	5000~ 2500倍	2000倍~ 1600倍	1000倍~ 600倍	10000分	5000分																																																																				
<p style="text-align: center;"><b>【遊戲倍率表】</b></p> 																																																																									
<p style="text-align: center;"><b>【遊戲按鍵配置】</b></p> 	<p style="text-align: center;"><b>【廣播報獎系統】</b></p> 																																																																								
<p style="text-align: center;"><b>【廣播報獎系統外接顯示器】</b></p> <p>本軟體將搭配以下框體：                  本遊戲共有 68 種框體，僅框體不同，遊戲內容皆相同。</p>																																																																									




機具名稱 中文：金龍彩  
 原文：DRAGON CASH


圖 片  
 介 紹




【831A】



【831B】




【831C】



【831D】



【ALL PASS】




【ALLPASS4030】

機具名稱 中文：金龍彩  
 原文：DRAGON CASH


圖 片  
 介 紹




【G6】




【G7】




【G11】









【H208 加燈片】









【H208】















【H333】

<p>機具名稱</p>	<p>中文：金龍彩                  原文：DRAGON CASH</p>
<p>圖 片 介 紹</p>	<div style="display: flex; flex-wrap: wrap; justify-content: space-around;"> <div style="text-align: center;">  <p>【Han-Xiang】</p> </div> <div style="text-align: center;">  <p>【HONG-TAI】</p> </div> <div style="text-align: center;">  <p>【MICK1】</p> </div> <div style="text-align: center;">  <p>【MICK2】</p> </div> <div style="text-align: center;">  <p>【NEW WAVE】</p> </div> <div style="text-align: center;">  <p>【S022】</p> </div> </div>



<p>機具名稱</p>	<p>中文：金龍彩                  原文：DRAGON CASH</p>
<p>圖 片 介 紹</p>	<div style="display: flex; flex-wrap: wrap;"> <div style="width: 50%; text-align: center;">  <p>【Wei-Tsang1】</p> </div> <div style="width: 50%; text-align: center;">  <p>【二合一】</p> </div> <div style="width: 50%; text-align: center;">  <p>【大風】</p> </div> <div style="width: 50%; text-align: center;">  <p>【大風 DD】</p> </div> <div style="width: 50%; text-align: center;">  <p>【和泰 921A】</p> </div> <div style="width: 50%; text-align: center;">  <p>【和泰 921B】</p> </div> </div>







<p>機具名稱</p>	<p>中文：金龍彩                  原文：DRAGON CASH</p>
<p>圖 片 介 紹</p>	<div style="display: flex; flex-wrap: wrap;"> <div style="width: 50%; text-align: center;">  <p>【和泰 921C】</p> </div> <div style="width: 50%; text-align: center;">  <p>【肯尼士】</p> </div> <div style="width: 50%; text-align: center;">  <p>【海豚機】</p> </div> <div style="width: 50%; text-align: center;">  <p>【富勝】</p> </div> <div style="width: 50%; text-align: center;">  <p>【富勝 2】</p> </div> <div style="width: 50%; text-align: center;">  <p>【富勝 3】</p> </div> </div>

<p>機具名稱</p>	<p>中文：金龍彩 原文：DRAGON CASH</p>
<p>圖 片 介 紹</p>	<div style="display: flex; flex-wrap: wrap;"> <div style="width: 50%; text-align: center;">  <p>【雄風】</p> </div> <div style="width: 50%; text-align: center;">  <p>【維亞 G13】</p> </div> <div style="width: 50%; text-align: center;">  <p>【歐巴斯】</p> </div> <div style="width: 50%; text-align: center;">  <p>【歐本】</p> </div> <div style="width: 50%; text-align: center;">  <p>【輪盤框體】</p> </div> <div style="width: 50%; text-align: center;">  <p>【懷益機台】</p> </div> </div>



<p>機具名稱</p>	<p>中文：金龍彩                  原文：DRAGON CASH</p>
<p>圖 片 介 紹</p>	<p>The image contains five photographs of slot machines, each with labels pointing to various components. The labels are: 遊戲倍率表 (Game Rate Table), 主遊戲畫面 (Main Game Screen), 開分鍵 (Open Key), 洗分鍵 (Reset Key), 投紙代幣孔 (Paper Coin Slot), 投代幣孔 (Coin Slot), 退代幣孔 (Coin Return Slot), and 按鍵區 (Control Panel).</p> <ul style="list-style-type: none"> <li><b>Figure 1 (Top Left):</b> A slot machine with a curved top and 'EGST' logo. Labels include 遊戲倍率表, 主遊戲畫面, 開分鍵, 洗分鍵, 投紙代幣孔, 投代幣孔, 退代幣孔, and 按鍵區.</li> <li><b>Figure 2 (Top Right):</b> A slot machine with a curved top and 'EGST' logo. Labels include 遊戲倍率表, 開分鍵, 洗分鍵, 主遊戲畫面, 投紙代幣孔, 投代幣孔, 退代幣孔, and 按鍵區.</li> <li><b>Figure 3 (Middle Left):</b> A slot machine with a curved top and 'LIDU' logo. Labels include 遊戲倍率表, 開分鍵, 洗分鍵, 主遊戲畫面, 投紙代幣孔, 投代幣孔, 退代幣孔, and 按鍵區.</li> <li><b>Figure 4 (Middle Right):</b> A slot machine with a curved top and 'LIDU' logo. Labels include 主遊戲畫面, 開分鍵, 洗分鍵, 主遊戲畫面, 投紙代幣孔, 投代幣孔, 退代幣孔, and 按鍵區.</li> <li><b>Figure 5 (Bottom Left):</b> A slot machine with a curved top and 'LIDU' logo. Labels include 遊戲倍率表, 開分鍵, 洗分鍵, 主遊戲畫面, 投紙代幣孔, 投代幣孔, 退代幣孔, and 按鍵區.</li> <li><b>Figure 6 (Bottom Right):</b> A slot machine with a curved top and 'LIDU' logo. Labels include 遊戲倍率表, 開分鍵, 洗分鍵, 主遊戲畫面, 投紙代幣孔, 投代幣孔, 退代幣孔, and 按鍵區.</li> </ul>

<p>機具名稱</p>	<p>中文：金龍彩                  原文：DRAGON CASH</p>
<p>圖 片                  介 紹</p>	<p>Figure 6: Front view of the machine showing the game rate table, open key, wash key, main game screen, paper coin slot, coin slot, coin return slot, and button area.</p> <p>Figure 7: Top-down view of the machine showing the game rate table, open key, wash key, main game screen, button area, coin slot, and coin return slot.</p> <p>Figure 8: Front view of the machine with a blue light effect, showing the game rate table, open key, wash key, main game screen, paper coin slot, coin slot, coin return slot, and button area.</p> <p>Figure 9: Front view of the machine with a green light effect, showing the game rate table, open key, wash key, main game screen, wash key, coin slot, paper coin slot, coin return slot, and button area.</p> <p>Figure 10: Front view of the machine with a blue light effect, showing the game rate table, open key, wash key, main game screen, paper coin slot, coin slot, coin return slot, and button area.</p> <p>Figure 11: Front view of the machine with a blue light effect, showing the game rate table, open key, wash key, main game screen, paper coin slot, coin slot, coin return slot, and button area.</p>

<p>機具名稱</p>	<p>中文：金龍彩                  原文：DRAGON CASH</p>
<p>圖 片 介 紹</p>	<div style="display: flex; flex-wrap: wrap; justify-content: space-around;"> <div style="text-align: center;">  <p>【12】</p> </div> <div style="text-align: center;">  <p>【13】</p> </div> <div style="text-align: center;">  <p>【14】</p> </div> <div style="text-align: center;">  <p>【15】</p> </div> <div style="text-align: center;">  <p>【16】</p> </div> <div style="text-align: center;">  <p>【17】</p> </div> </div>



<p>機具名稱</p>	<p>中文：金龍彩 原文：DRAGON CASH</p>
<p>圖 片 介 紹</p>	<p>The figure shows six different views of the Dragon Cash slot machine, each with labeled components:</p> <ul style="list-style-type: none"> <li><b>Figure [18]:</b> Front view of the machine with 'sheng' logo at the top. Callouts include: 遊戲倍率表 (Game Multiplier Table), 洗分鍵 (Reset Button), 開分鍵 (Open Button), 主遊戲畫面 (Main Game Screen), 按鍵區 (Button Area), 投代幣孔 (Coin Insertion Slot), and 退代幣孔 (Coin Return Slot).</li> <li><b>Figure [19]:</b> Front view of the machine with 'LIDU' logo at the bottom. Callouts include: 遊戲倍率表, 洗分鍵, 開分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, and 退代幣孔.</li> <li><b>Figure [20]:</b> Front view of the machine. Callouts include: 遊戲倍率表, 洗分鍵, 開分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, and 退代幣孔.</li> <li><b>Figure [21]:</b> Front view of the machine. Callouts include: 遊戲倍率表, 洗分鍵, 開分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, and 退代幣孔.</li> <li><b>Figure [22]:</b> Front view of the machine with 'LIDU' logo at the top. Callouts include: 遊戲倍率表, 洗分鍵, 開分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, and 退代幣孔.</li> <li><b>Figure [23]:</b> Front view of the machine with 'LIDU' logo at the top. Callouts include: 遊戲倍率表, 洗分鍵, 開分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, and 退代幣孔.</li> </ul>

<p>機具名稱</p>	<p>中文：金龍彩                  原文：DRAGON CASH</p>
<p>圖 片 介 紹</p>	<p>Figure 24: Slot machine with labels: 遊戲倍率表, 洗分鍵, 開分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, 退代幣孔.</p> <p>Figure 25: Slot machine with labels: 遊戲倍率表, 洗分鍵, 開分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, 退代幣孔.</p> <p>Figure 801: Slot machine with labels: 遊戲倍率表, 洗分鍵, 開分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, 退代幣孔, 投紙代幣孔.</p> <p>Figure 806: Slot machine with labels: 遊戲倍率表, 主遊戲畫面, 洗分鍵, 開分鍵, 按鍵區, 投代幣孔, 退代幣孔.</p> <p>Figure G13: Slot machine with labels: 遊戲倍率表, 主遊戲畫面, 投代幣孔, 按鍵區, 退代幣孔.</p> <p>Figure LITBOY-01: Slot machine with labels: 開分鍵, 洗分鍵, 主遊戲畫面, 按鍵區, 投代幣孔, 退代幣孔.</p>

